



## End Plate

End Plates are used to cover the live parts of the last Terminal Block

| PRODUCT SPECIFICATION |         |  |
|-----------------------|---------|--|
| Height                | 30.5 mm |  |
| Length                | 74.7 mm |  |
| Width (Thickness)     | 1.5 mm  |  |

| ORDERING INFORMATION |   |           |  |
|----------------------|---|-----------|--|
| CAT. NO.             | DESCRIPTION                             | STD. PACK |  |
| EPCX2.5/4            | END PLATE FOR CX2.5/4&CXK2.5/4&CXK2.5/4 | 50        |  |
| EPCX2.5/40           | END PLATE FOR CX2.5/4 ORANGE            | 50        |  |

| SUITABLE FOR |  |  |
|--------------|--|--|
| CP2.5/4      | 2.5 sq.mm Push in Feed Through compact Terminal Blocks             |  |
| CX2.5/4P     | CX2.5/4P, feed through spring clamp compact Terminal block.        |  |
| CX2.5/4      | 2.5 sq.mm Spring Clamp Feed Through compact Terminal Blocks        |  |
| CXCP2.5/4    | 2.5 sq.mm Spring Clamp Feed Through compact Terminal Blocks        |  |
| CXG2.5/4/2B  | 2.5 sq.mm Ground/Earth Spring Clamp<br>Terminal Blocks             |  |
| CPG2.5/4     | 2.5 sq.mm Ground/Earth Push in Terminal Blocks                     |  |
| CXCC2.5/4    | 2.5 sq.mm Component carrier spring clamp terminal block            |  |
| CXG2.5/4     | 2.5 sq.mm Ground/Earth Spring Clamp<br>Terminal Blocks             |  |
| CXK2.5/4     | 2.5 sq.mm Spring Clamp knife disconnecting compact Terminal Blocks |  |
|              |  |  |